
Bobcat® LT102

Trencher Replacement Parts



Faster Service Better Quality Lower Prices

Replacement Parts for Bobcat® Trencher Attachments

Bobcat[®] is a registered trade mark of Bobcat Company.

All manufacturers' names, numbers, symbols and descriptions are used for reference purposes only and it is not implied that any parts listed are the products of the manufacturers.

Main Office 840 McKinley Street Anoka, Minnesota 55303 Branch Office 675 Wesleyan Drive South West Atlanta, Georgia 30336 Branch Office 9647 Santa Fe Springs Rd. Santa Fe Springs, California 90670

Call Toll Free To Inside Sales 1/800/328/2424 FAX 1-763-427-2277

Email: parts@ballantineinc.com www.ballantineinc.com



Bobcat® LT102 Attachment



Bare Chain 1.654" Pitch Every 4th Ballantine Part No. Dig Depth Description ZB1640400B13 24" Bare Chain 13 Station ZB1640400B17 36" Bare Chain 17 Station



Bare Chain 1.654" Pitch Every 2nd Ballantine Part No. Dig Depth Description ZB1640200B26 24" Bare Chain 26 Station ZB1640200B34 36" Bare Chain 34 Station



Bare Chain 1.654" Pitch Heavy Duty Anti Back Flex Ballantine Part No. Dig Depth Description TA1654HD00B26 24" Bare Chain 26 Station TA1654HD00B34 36" Bare Chain 34 Station

Ballantine • 840 McKinley St., Anoka, MN 55303 Phone: 800-328-2424 (US only) or 763-427-3959

Bobcat® LT102 Attachment



Cup Cutter Assemblies 1.654" Pitch Every 4th			
Ballantine Part No.	Dig Depth	Description	
M564044C13	24"	Cup Cutter Assembly 4" Cut 13 Station	
M564044C17	36"	Cup Cutter Assembly 4" Cut 17 Station	
M564064C13	24"	Cup Cutter Assembly 6" Cut 13 Station	
M564064C17	36"	Cup Cutter Assembly 6" Cut 17 Station	
Wider Cutting Widths Available Upon Request			



Cup Cutter Assemblies 1.654" Pitch Every 2nd			
Ballantine Part No.	Dig Depth	Description	
M564042C26	24"	Cup Cutter Assembly 4" Cut 26 Station	
M564042C34	36"	Cup Cutter Assembly 4" Cut 34 Station	
M564062C26	24"	Cup Cutter Assembly 6" Cut 26 Station	
M564062C34	36"	Cup Cutter Assembly 6" Cut 34 Station	
Wider Cutting Widths Available Upon Request			



Ballantine Part No. Anti Back Flex Cup Cutter Assemblies, 1.654" Every Second		
	Dig Depth	Description
M1654HD042C26	24"	Cup Cutter Assembly 4" Cut 26 Station
M1654HD042C34	36"	Cup Cutter Assembly 4" Cut 34 Station
M1654HD062C26	24"	Cup Cutter Assembly 6" Cut 26 Station
M1654HD062C34	36"	Cup Cutter Assembly 6" Cut 34 Station
Wider Cutting Widths Available Upon Request		



Bobcat® LT102 Attachment



Terminator & Cup Combination Assemblies, 1.654" Every 2nd

Ballantine Part No.	Dig Depth	Description
ZB164042TM26	24"	1/2 Terminator & 1/2 Cup 4" Cut 26 Station
ZB164042TM34	36"	1/2 Terminator & 1/2 Cup 4" Cut 34 Station
ZB164062TM26	24"	1/2 Terminator & 1/2 Cup 6" Cut 26 Station
ZB164062TM34	36"	1/2 Terminator & 1/2 Cup 6" Cut 34 Station
Wider Cutting Widths Available Upon Request		



Heavy Duty Anti Back Flex Terminator & Cup Combination Assemblies, 1.654" Every 2nd

Ballantine Part No.	Dig Depth	Description
T1654HD042M26	24"	1/2 Terminator & 1/2 Cup 4" Cut 26 Station
T1654HD042M34	36"	1/2 Terminator & 1/2 Cup 4" Cut 34 Station
T1654HD062M26	24"	1/2 Terminator & 1/2 Cup 6" Cut 26 Station
T1654HD062M34	36"	1/2 Terminator & 1/2 Cup 6" Cut 34 Station
Wider Cutting Widths Available Upon Request		



Bolt On Terminator Assemblies, 1.654" Every 2nd

Ballantine Part No.	Dig Depth	Description
ZB164042T26	24"	Terminator Bolt On 4" Cut 26 Station
ZB164042T34	36"	Terminator Bolt On 4" Cut 34 Station
ZB164062T26	24"	Terminator Bolt On 6" Cut 26 Station
ZB164062T34	36"	Terminator Bolt On 6" Cut 34 Station
Wider Cutting Widths Available Upon Request		



Heavy Duty Anti Back Flex Bolt On Terminator Assemblies, 1.654" Every 2nd

Ballantine Part No.	Dig Depth	Description
T1654HD042T26	24"	Terminator Bolt On 4" Cut 26 Station
T1654HD042T34	36"	Terminator Bolt On 4" Cut 34 Station
T1654HD062T26	24"	Terminator Bolt On 6" Cut 26 Station
T1654HD062T34	36"	Terminator Bolt On 6" Cut 34 Station
Wider Cutting Widths Available Upon Request		

Bobcat® LT102 Attachment



Rock & Cup Combination Assemblies, 1.654" Every 2nd

Ballantine Part No.	Dig Depth	Description
ZB164042RM26	24"	1/2 Carbide & 1/2 Cup 4" Cut 26 Station
ZB164042RM34	36"	1/2 Carbide & 1/2 Cup 4" Cut 34 Station
ZB164062RM26	24"	1/2 Carbide & 1/2 Cup 6" Cut 26 Station
ZB164062RM34	36"	1/2 Carbide & 1/2 Cup 6" Cut 34 Station
Wider Cutting Widths Available Upon Request		



Heavy Duty Anti Back Flex Rock & Cup Combination Assemblies, 1.654" Every 2nd

Ballantine Part No.	Dig Depth	Description
TA1654HD042M26	24"	1/2 Carbide & 1/2 Cup 4" Cut 26 Station
TA1654HD042M34	36"	1/2 Carbide & 1/2 Cup 4" Cut 34 Station
TA1654HD062M26	24"	1/2 Carbide & 1/2 Cup 6" Cut 26 Station
TA1654HD062M34	36"	1/2 Carbide & 1/2 Cup 6" Cut 34 Station
Wider Cutting Widths Available Upon Request		



Rock & Frost Assemblies, 1.654" Every 2nd

Ballantine Part No.	Dig Depth	Description
ZB164042R26	24"	Rock & Frost Assembly 4" Cut 26 Station
ZB164042R34	36"	Rock & Frost Assembly 4" Cut 34 Station
ZB164062R26	24"	Rock & Frost Assembly 6" Cut 26 Station
ZB164062R34	36"	Rock & Frost Assembly 6" Cut 34 Station
Wider Cutting Widths Available Upon Request		



Heavy Duty Anti Back Flex Rock & Frost Assemblies, 1.654" Every 2nd

Ballantine Part No.	Dig Depth	Description
TA1654HD042R26	24"	Rock & Frost Assembly 4" Cut 26 Station
TA1654HD042R34	36"	Rock & Frost Assembly 4" Cut 34 Station
TA1654HD062R26	24"	Rock & Frost Assembly 6" Cut 26 Station
TA1654HD062R34	36"	Rock & Frost Assembly 6" Cut 34 Station
Wider Cutting Widths Available Upon Request		



Bobcat® LT102 Attachment



Heavy Duty Anti Back Flex Terminator Chain

Ballantine Part No.	Dig Depth	Description
SH165404S26	24"	Terminator Chain 4" Cut 26 Station
SH165404S34	30"	Terminator Chain 4" Cut 34 Station
Wider Cutting Widths Available Upon Request		



Heavy Duty Anti Back Flex Alligator Chain

Ballantine Part No.	Dig Depth	Description
AL16540426	24"	Alligator Chain 4" Cut 26 Station
AL16540434	30"	Alligator Chain 4" Cut 34 Station
Wider Cutting Widths Available Upon Request		

Bobcat® LT102 Attachment

Chain Componets For 1.654 Every 4th, Every 2nd And Heavy Duty Anti Back Flex

Chain Repair Components



Ballantine Part No.	OEM Part Number	Description
B208454	N/A	Connecting Pin & Keeper
Ballantine Part No.	OEM Part Number	Description
		B208454 N/A



Ballantine Part No.	OEM Part Number	Description
B135007	N/A	Cotter Pin
Ballantine Part No.	OEM Part Number	Description
ZB1640400B01	N/A	Chain Repair Section Every Fourth
Ballantine Part No.	OEM Part Number	Description
ZB1640200B01	N/A	Chain Repair Section Every Second



	Ballantine Part No.	OEM Part Number	Description
•	TA1654HD00B01	N/A	Heavy Duty Anti Back Flex Chain Repair Section Every Second



Cup Cutters

Ballantine Part No.	OEM Part Number	Description
6655759	6655759	Cup Cutter Right Hand
Ballantine Part No.	OEM Part Number	Description
6655760	6655760	Cup Cutter Left Hand



Terminators

Ballantine Part No.	OEM Part Number	Description
T165404R	N/A	Terminator Adapter Right Hand
Ballantine Part No.	OEM Part Number	Description
T165404L	N/A	Terminator Adapter Left Hand
Ballantine Part No.	OEM Part Number	Description
T165404C	N/A	Terminatr Adapter Straight Cut





Ballantine Part No.	OEM Part Number	Description
B135318	N/A	Rock & Frost Adapter Right Hand
Ballantine Part No.	OEM Part Number	Description
B135317	N/A	Rock & Frost Adapter Left Hand
Ballantine Part No.	OEM Part Number	Description
B135316	N/A	Rock & Frost Adapter Straight Cut
D. II II. D M	0=14.5 . 1	5
Ballantine Part No.	OEM Part Number	Description
B17	N/A	Carbide Bit With Clip
Ballantine Part No.	OEM Part Number	Description
B17D	N/A	Clip



Flat Spacers



Ballantine Part No.	OEM Part Number	Description
B208355	N/A	Flat Spacer 5/16" Thick
Ballantine Part No.	OEM Part Number	Description
BL1654-5	N/A	Flat Spacer 1/2" Thick
B210010		That opador 1/2 Trilon
Ballantine Part No.	OEM Part Number	Description
BL1654-6	N/A	Flat Spacer 1" Thick



Bobcat® LT102 Attachment

Chain Componets For 1.654 Every 4th, Every 2nd And Heavy Duty Anti Back Flex

Adapters For 1.654" Pitch Every 4th And Every 2nd



	Ballantine Part No.	OEM Part Number	Description
	B208439	N/A	Adapter For 8" Cut
1	Ballantine Part No.	OEM Part Number	Description
	B208477	N/A	Adapter For 10" Cut
	Ballantine Part No.	OEM Part Number	Description
	B564781	N/A	Adapter For 12" Cut

Adapters For 1.654" Pitch Heavy Duty Anti Back Flex



Ballantine Part No.	OEM Part Number	Description
PL1654HD8	N/A	Adapter For 8" Cut
Ballantine Part No.	OEM Part Number	Description
PL1654HD10	N/A	Adapter For 10" Cut
Ballantine Part No.	OEM Part Number	Description
PL1654HD12	N/A	Adapter For 12" Cut

Tube Spacers



Ballantine Part No.	OEM Part Number	Description
B138009	N/A	Tube Spacer For Outside Mounting
Ballantine Part No.	OEM Part Number	Description
B138010	N/A	Tube Spacer Rock & Frost Mounted Inside
Ballantine Part No.	OEM Part Number	Description
B136032S	N/A	Tube Spacer Cup Cutter Mounted Inside

Bolts



Dellantina Dant Na	OFM Post Noveless	Description	
Ballantine Part No.	OEM Part Number	Description	
3824788	N/A	Bolt 3/8" X 24 X 7/8" Grade 8	
Ballantine Part No.	OEM Part Number	Description	
34241148	N/A	Bolt 3/8" X 24 X 1 1/4" Grade 8	
Ballantine Part No.	OEM Part Number	Description	
38242148	N/A	Bolt 3/8" X 24 X 2 1/4" Grade 8	
Ballantine Part No.	OEM Part Number	Description	
38242128	N/A	Bolt 3/8" X 24 X 2 1/2" Grade 8	
Ballantine Part No.	OEM Part Number	Description	
38242348	N/A	Bolt 3/8" X 24 X 2 3/4" Grade 8	
Ballantine Part No.	OEM Part Number	Description	
382438	N/A	Bolt 3/8" X 24 X 3" Grade 8	
Ballantine Part No.	OEM Part Number	Description	
38243148	N/A	Bolt 3/8" X 24 X 3 1/4" Grade 8	
	1		



002400	14/71	Bolt 6/6 XZ+X6 Glade 6
Ballantine Part No.	OEM Part Number	Description
38243148	N/A	Bolt 3/8" X 24 X 3 1/4" Grade 8
Ballantine Part No.	OEM Part Number	Description
38243128	N/A	Bolt 3/8" X 24 X 3 1/2" Grade 8
Ballantine Part No.	OEM Part Number	Description
3824	N/A	Lock Nut 3/8" X 24
Ballantine Part No.	OEM Part Number	Description
382S	N/A	Flat Washer



Bobcat® LT102 Attachment

Sprocket



Ballantine Part No.	OEM Part Number	Description
6705174	6705174	Drive Sprocket Solid 11 Tooth

Boom Components



Ballantine Part No.	OEM Part Number	Description
6577026	6577026	Boom End Roller



Ballantine Part No.	OEM Part Number	Description
6577026A	N/A	Boom End Roller Assembly



Ballantine Part No.	OEM Part Number	Description
6576140	6576140	Bearing Square Hole



Ballantine Part No.	OEM Part Number	Description
6645545	6645545	Snap Ring



Ballantine Part No.	OEM Part Number	Description
6577025	6577025	Dirt Shield (2 Reqired)



Ballantine Part No.	OEM Part Number	Description
6577011	6577025	Idler Shaft



Ballantine Part No.	OEM Part Number	Description
12131	35C000816B	Idler Shaft Bolt (2 Required)



Ballantine Part No.	OEM Part Number	Description
12FW	6675521	Idler Shaft Washer (2 Required)



Ground Engaging Parts Specialists

Corporate Headquarters: 840 McKinley Street, Anoka, MN 55303 Warehouse: 9647 Sante Fe Springs Rd., Sante Fe Springs, CA 90680 Warehouse: 675 Wesleyan Drive SW, Atlanta, GA 30336

www.ballantineinc.com

phone: 800-328-2424 • fax 763-427-2277 • parts@ballantineinc.com

°2016 U.S. Tsubaki Power Transmission, LLC. All Rights Reserved Printed in the U.S.A. 05/17